


DOPPLER ARM
3B40.10



USE "FAST" MOTOR FOR DOPPLER ARM. CONTROL SPEED AT CONTROL BOX. START OUT SLOW THEN SPEED UP.

SPEAKER SWITCH IS ON CLEAR BOX. TURN ON BEFORE STARTING ARM MOTOR. SPEAKER IS RUN BY A SEPARATE BATTERY INSIDE THE BOX. CHECK FOR POWER.

BE AWARE OF ARM SWING. DO NOT GET WHACKED IN THE FACE WHEN CHANGING SPEED OF ARM.